



View
HC106
Load Moment Indicator
Troubleshooting-Repair Manual



6.28.19 TME Rev 9
Software 1.0-1.5A4



Office: 815.270.0088
Email: info@controlsystemsw.com

Table of Contents

Clearing stored alarm codes	Page 4
Alarm codes and conditions	Page 5-6
Alarm 6, 7 and 8 (Length)	Page 7
Alarm 15 & 25 (Angle)	Page 8
Alarm 12 & 22 (Piston pressure sensor)	Page 9
Alarm 13 & 23 (Rod Pressure sensor)	Page 10
Alarm 56 EEPROM fault	Page 11
Alarm 190 Head Can Communication	Page 11
Alarm 191 Slope sensor	Page 11
Engine faults	Page 12
A-2-B Faults	Page 13
Cable reel cable replacement	Page 14-21
Angle adjustment	Page 22
Length adjustment	Page 23
A-2-B wiring	Page 25
Pressure sensors	Page 25
Wiring Diagram	Page 26
Wiring Diagram new	Page 27
Engine ICONS	Page 28
System layout	Page 29
Manual revision changes	Page 30

IMPORTANT TROUBLESHOOTING NOTE !


Prior to troubleshooting the View HC system, a simple check of the unit is necessary to avoid extended time. When the system is powered up it performs a self test of all components. During this self test if any components are disconnected or faulty it will indicate alarms in the message area code 6, 12, 13 and 190.

This indicates that components did not pass the self test for communication, which creates the 190 communication code. A simple check is required to see the true faults if any by confirming the system by program, then once the unit has cleared and alarm codes are present press and release the Tare/ESC pushbutton on the display. The system will clear all non-faulted alarm code and display the faulted components codes only.

Low Fuel Level; The unit is equipped to indicate a Low fuel level text message on the display when the fuel level is at 12% or lower.

View

The View system will store and indicate the alarm code on the display. First we should press and release the TARE/ESC pushbutton to clear any stored alarms. If more than one alarm is stored it will clear the first, then display the next one. To clear this press and release the TARE/ESC pushbutton, prior to troubleshooting the system.



The ICONS on the right hand side of the display indicate the condition of the system.

Hook Block Icon When clear no A-2-B condition. When it turns RED, system is in A-2-B condition.

OK Icon When it turns GREEN, system is operational, no conditions or alarms are present.

STOP Icon When Clear system is operational. When it turns RED system is in a condition or alarm is present. Lock out system is de-energized.

Alarm/Fault codes

<i>MESSAGE</i>	<i>CAUSE</i>	<i>SOLUTION</i>
<ul style="list-style-type: none"> • <i>ALARM 6</i> <i>Length output too Low</i> 	<ul style="list-style-type: none"> • <i>Potentiometer inside Reel is faulty .</i> • <i>Possible lack of continuity in wires carrying the signals</i> • <i>Fault in main unit.</i> • <i>Length requires adjustment.</i> 	<ul style="list-style-type: none"> • <i>Check cable drum spooling is proper</i> • <i>Check Wiring from cable reel to Head Unit</i> • <i>Check 5vdc supply to length pot in cable reel and output fully retracted is 0.249-0.251vdc</i> • <i>Replace pot if damaged</i>
<ul style="list-style-type: none"> • <i>ALARM 7</i> <i>Length output too High</i> 	<ul style="list-style-type: none"> • <i>Potentiometer inside Reel is faulty.</i> • <i>Possible lack of continuity in wires carrying the signals</i> • <i>Fault in main unit.</i> • <i>Length requires adjustment</i> 	<ul style="list-style-type: none"> • <i>Check cable drum spooling is proper</i> • <i>Check Wiring from cable reel to Head Unit</i> • <i>Check 5vdc supply to length pot in cable reel</i> • <i>Replace pot if damaged</i>
<ul style="list-style-type: none"> • <i>ALARM 8</i> <i>Length output actual too low</i> 	<ul style="list-style-type: none"> • <i>Potentiometer inside Reel is faulty.</i> • <i>Possible lack of continuity in wires carrying the signals</i> • <i>Fault in main unit.</i> 	<ul style="list-style-type: none"> • <i>Check Wiring from cable reel to Head Unit</i> • <i>Check 5vdc supply to length pot in cable reel</i> • <i>Check output fully retracted 0.249-0.251vdc</i> • <i>Replace pot if damaged</i> • <i>Call service</i>
<ul style="list-style-type: none"> • <i>ALARM 12</i> <i>Piston Pressure Sensor output too Low</i> 	<ul style="list-style-type: none"> • <i>Piston pressure transducer damaged</i> • <i>Possible lack of continuity in connection wires</i> • <i>Fault in main unit</i> • <i>Hydraulic fluid in connector contacts</i> 	<ul style="list-style-type: none"> • <i>Check for 15vdc supply</i> • <i>Check for output 0.5 vdc min</i> • <i>Check connection wires.</i> • <i>Check connector for fluid on transducer and check wiring</i> • <i>Replace Transducer if faulty</i> • <i>Call service</i>
<ul style="list-style-type: none"> • <i>ALARM 13</i> <i>Rod Pressure Sensor output too Low</i> 	<ul style="list-style-type: none"> • <i>Rod pressure transducer damaged</i> • <i>Possible lack of continuity in connection wires</i> • <i>Fault in main unit</i> • <i>Hydraulic fluid in connector</i> 	<ul style="list-style-type: none"> • <i>Check for 15vdc supply</i> • <i>Check for output 0.5 vdc min</i> • <i>Check connection wires.</i> • <i>Check connector for fluid on transducer and check wiring</i> • <i>Replace Transducer if faulty</i> • <i>Call service</i>

Alarm/Fault codes

MESSAGE	CAUSE	SOLUTION
<ul style="list-style-type: none"> • ALARM 15 <i>Angle output too Low</i> 	<ul style="list-style-type: none"> • <i>Angle Sensor inside Reel is faulty.</i> • <i>Possible lack of continuity in wires carrying the signals</i> • <i>Fault in main unit</i> 	<ul style="list-style-type: none"> • <i>Check Wiring from cable reel to Head Electronic</i> • <i>Check 5vdc supply to angle sensor in cable reel</i> • <i>Check output zero degrees 2.49-2.51 vdc</i> • <i>Replace Angle Sensor if faulty</i> • <i>Call service</i>
<ul style="list-style-type: none"> • ALARM 22 <i>Piston Pressure Sensor output too High</i> 	<ul style="list-style-type: none"> • <i>Piston pressure transducer damaged</i> • <i>Possible lack of continuity in connection wires</i> • <i>Fault in main unit</i> • <i>Hydraulic fluid in connector contacts</i> 	<ul style="list-style-type: none"> • <i>Check for 15vdc supply</i> • <i>Check for output</i> • <i>Check connection wires.</i> • <i>Check connector for fluid on transducer and check wiring</i> • <i>Replace Transducer if faulty</i> • <i>Call service</i>
<ul style="list-style-type: none"> • ALARM 23 <i>Rod Pressure Sensor output too High</i> 	<ul style="list-style-type: none"> • <i>Rod pressure transducer damaged</i> • <i>Possible lack of continuity in connection wires</i> • <i>Fault in main unit</i> • <i>Hydraulic fluid in connector contacts</i> 	<ul style="list-style-type: none"> • <i>Check for 15vdc supply</i> • <i>Check for output</i> • <i>Check connection wires.</i> • <i>Check connector for fluid on transducer and check wiring</i> • <i>Replace Transducer if faulty</i> • <i>Call service</i>
<ul style="list-style-type: none"> • ALARM 25 <i>Angle output too High</i> 	<ul style="list-style-type: none"> • <i>Angle Sensor inside Reel is faulty.</i> • <i>Possible lack of continuity in wires carrying the signals</i> • <i>Fault in main unit</i> 	<ul style="list-style-type: none"> • <i>Check Wiring from cable reel to Head Electronic</i> • <i>Check 5vdc supply to angle sensor in cable reel</i> • <i>Check output max is 5.00vdc</i> • <i>Replace Angle Sensor if faulty</i> • <i>Call service</i>
<ul style="list-style-type: none"> • ALARM 56 <i>EEPROM View</i> 	<ul style="list-style-type: none"> • <i>Memory problem in View Display</i> 	<ul style="list-style-type: none"> • <i>Call service</i>
<ul style="list-style-type: none"> • ALARM 190 <i>Head Communication</i> 	<ul style="list-style-type: none"> • <i>Error in comm.</i> 	<ul style="list-style-type: none"> • <i>Check 56 pin connector on Head and 4 pin connector on View.</i> • <i>Call Service</i>
<ul style="list-style-type: none"> • ALARM 191 <i>ASA Slope Sensor</i> 	<ul style="list-style-type: none"> • <i>No Communication between ASA Slope Sensor and Head Unit</i> 	<ul style="list-style-type: none"> • <i>Check 4 pin connector on ASA.</i> • <i>Call service</i>

System Alarm Codes

Alarm Code 6 , 7 & 8 (Length Sensor)

This code is caused by the output voltage of the length sensor is lower (code 6) than the minimum, higher (code 7) than the maximum voltage or higher than the actual value (code8).

Actions to take; Level the machine, Fully retract the boom and lower the angle to zero degrees.

1. Check the cable is spooling properly on the drum. If cable is built up on one side of drum correct it and adjust the roller guide to correct.
2. Remove the cover of the cable reel using a m3 allen wrench and check the +5.00vdc (Typically the voltage is about 4.94vdc) supply voltage (Brown wire) and the ground wire (white wire). See Fig 5. If the voltage is ok continue to step 2, if not check the wiring from the cable reel to the Head electronic and boom base connector for damage.
3. Check the output of the length sensor. The output of the length sensor when the boom is fully retracted should be approximately 0.250vdc.(Yellow wire), (tolerance 0.249 to 0.251vdc is OK). If it is higher or lower check the wiring first for damage. If the wiring is ok, press down on the length pot swing arm(Fig 6) and adjust the gear until the display indicates what the minimum boom length for that model of machine. Check the voltage and record this for later use.
4. If adjusting the length gear assembly and the length does not change on the display, remove the output (Yellow) wire and check if the voltage changes, if not change the length pot and adjust the length.




Fig 5




Fig 6

System Alarm Codes

Alarm Code 15 or 25 (Angle Sensor)

This code is caused by the output voltage of the angle sensor is lower (code 15) than the minimum or higher (code 25) than the maximum voltage.

Actions to take; Level the machine, Fully retract the boom and lower the angle to zero degrees using a angle finder to determine zero degrees. All wire color is the connection cable coming from the cab. See figure 3.

1. *Remove the cover of the cable reel using a m3 allen wrench and check the +5.00vdc (Typically the voltage is about 4.94vdc) supply voltage (Brown wire) and the ground wire (white wire). See Fig 3. If the voltage is ok continue to step 2, if not check the wiring from the cable reel to the Head electronic and boom base connector for damage.*
2. *Check the output of the angle sensor. The output of the angle when the boom is at zero degrees should be approximately 2.50vdc.(Green wire), (tolerance 2.49 to 2.51vdc is OK). If it is higher or lower check the wiring first for damage. If the wiring is ok, loosen the three screws (Fig 4) on the angle pot and adjust the pot until the display indicates what the angle finder indicates. Check the voltage and record this for later use.*
3. *If adjusting the angle pot and the angle does not change on the display, remove the output (Green) wire and check if the voltage changes, if not change the angle pot and adjust the angle in step 2.*
4. *Call for service if angle is still incorrect..*

Fig 3





Fig 4



System Alarm Codes


Alarm Code 12 or 22 (Piston Sensor)

This code is caused by the output voltage of the piston pressure sensor is lower (code 12) than the minimum or higher (code 22) than the maximum voltage.

Actions to take; Fully retract the boom and lower the angle to zero degrees. Pressure Sensors are located on the holding valves of the lift cylinders. See figure 7.

1. *Using a flat tip screwdriver loosen the screw on the connectors and switch the connector and see if the code changes to the opposite sensor, if it does check the wiring from the head electronic to the sensor and check that air is not creating the code by bleeding the sensor or hydraulic fluid is in the connector.*
2. *Check the supply voltage and ground at the connector end. See figure 7. If the code does not change and wiring is ok bleed pressure sensor or replace it.*
3. *Supply voltage for pressure sensors is 10-30vdc, Output with no load should be around .70 to .90vdc*
4. *Call for service if code is still present.*

Fig 7



PIN 3 Wires

- | | |
|---|----------------------------|
| 1 | +VB |
| 2 | output signal 0,5 .. 5,5 V |
| 3 | GND |

System Alarm Codes


Alarm Code 13 or 23 (Rod Sensor)

This code is caused by the output voltage of the rod pressure sensor is lower (code 13) than the minimum or higher (code 23) than the maximum voltage.

Actions to take; Fully retract the boom and lower the angle to zero degrees. Pressure Sensors are located on the holding valves of the lift cylinders. See figure 8.

1. Using a flat tip screwdriver loosen the screw on the connectors and switch the connector and see if the code changes to the opposite sensor, if it does check the wiring from the head electronic to the sensor and check that air is not creating the code by bleeding the sensor or hydraulic fluid is in the connector.
2. Check the supply voltage and ground at the connector end. See figure 8. If the code does not change and wiring is ok bleed pressure sensor or replace it.
3. Supply voltage for pressure sensors is 10-30vdc, Output with no load should be around .50 to .70vdc
4. Call for service if code is still present.

Fig 8



PIN 3 Wires

- | | |
|---|----------------------------|
| 1 | +VB |
| 2 | output signal 0,5 .. 5,5 V |
| 3 | GND |

System Alarm Codes

Alarm 56 EEPROM fault View

1. *Cycle power on the display and check, press and release the TARE/ESC pushbutton to clear.*
2. *CALL SERVICE*

Alarm code190 Communication from Head electronic

1. *Check that 56 pin connector on the head is connected*
2. *Check cable from View to Head for continuity.*
3. *Replace Head or CALL SERVICE*

Alarm Code 191 ASA Slope Sensor

1. *Check 4 pin connector on slope sensor is connected.*
2. *Check wiring between slope sensor and head electronic for continuity*
3. *Replace Slope sensor or CALL SERVICE*

NOTE

Do not check wiring for output from any can bus component when power is applied to the system. Damage to the system will be the result

System Fault Conditions

Engine Speed control; idle, speed 1 and speed 2 settings(F1, F2 or F3 pushbuttons)

See page 27 for more information

1. Check wiring between View Display and Cummins ECM module for damage. See wiring diagram.
2. Check relays in control box.
3. Call Service

Engine faults Icons;Outputs from the Cummins ECM module to enable these functions.

Functions from the Cummins ECM are Oil pressure, Water temperature, Oil Temperature, Battery level, RPM, SPN, FMI and Hour meter.

1. Check wiring harness from Head to ECM. See wiring diagram.
2. Call Service

Digital outputs from machine sensors;

Air filter, Hydraulic Oil temperature, Pilot Filter, Hydraulic filter, Water in Fuel, and Fuel level.

1. Check wiring harness from Head to machines sensors. See wiring diagram
2. Call Service



System Fault Conditions

A-2-B alarm (A-2-B Switch) The display hook block icon turns RED indicating an A-2-B condition

This code is caused by an open circuit in the A-2-B switch.

Actions to take; Fully retract the boom and lower the angle to zero degrees.

1. *Check if the machine is in a A-2-B condition, lower hook block.*
2. *Check if the cable or connectors are damaged between the switch to the electronic in the cab.*
3. *Remove the four screws in the switch cover and check the micro-switch for continuity. or 10-30vdc supply voltage.*
4. *Check for moisture, dry and seal connector.*
5. *Replace the switch or cable.*
6. *Call for service if code is still present.*

Fig 9




Cable replacement

Remove the four mounting bolts and remove the reel from the boom. Remove the cable reel cover by removing the four screws on the cover with a m3 Allen wrench (Fig 12). Then remove the cover (Fig 13).

Fig 12



Fig 13



Cable replacement

Remove all tension from the cable reel to avoid injury or damage to the spring package of the cable reel.

First step to replace the three conductor cable is to remove the black connector from the end of the cable to reuse it later (Fig 14). Then we will need to remove the cable reel from the boom of the machine in order to replace the cable. Remove the four bolts from the bracket and set the reel on a surface that will not damage it (Fig 15).



Fig 14




Fig 15


Cable replacement

Remove all the cable from the cable reel drum and push up the cable protective loom and cut it off at the back side of the cable reel (Fig 16). Lay the cable reel on its mounting bracket to access the front area (Fig 17).

Fig 16



Fig 17



Cable replacement

Remove three self locking nuts using a 10mm wrench (Fig 18). Carefully remove the plastic slip ring cover cap (Fig 19). You may require using a flat tip screwdriver to pry it . Insert the tip of the screwdriver just enough to catch the side of the cap. **DO NOT INSERT IT TOO DEEP OR YOU CAN DAMAGE THE SLIPRING!**

Fig 18





Fig 19

Using the screwdriver tip to carefully pry up the cap to access the wiring. Use the hardware as a lever for the screwdriver.




Cable replacement

Now that the cap is removed we can remove the existing cable. Remove the four Phillips head screws, noting the color code and location on the slip ring. Cut the ring terminals off.

(Fig 20).

Fig 20




Wiring code
Collector

Bottom = White
Middle = Red
Top = Blue
Shield = base



Cable replacement

Set the cable reel on its side, loosen the pg strain relief connector and remove the cable (Fig 21).



Strip back one end of the replacement cable the same length as the old cable or approximately 12 inches and feed it through the cable reel drum access hole from the inside of the drum area and then into the base connector and up into the slip ring collector (Fig 22).




Fig 22



Cable replacement


The cable inserted into the pg strain relief must have the outer jacket on in order for the strain relief to work. Tighten the pg connector strain relief nut. Cut off any access wire inside the slip ring and install the ring terminal and connect the wire to the proper terminal of the slip ring collector. See page 23 for wiring.

Tighten the phillips screws and replace the cap and self locking nuts.



Cable replacement

Install the replacement cable back onto the drum and install it back on the boom. Feed the cable through the guides to the boom tip and connect the strain relief and the black connector. The tension on the reel will be automatic when you pull out the cable. If not tension the reel 3 to 5 wraps and then route it to the boom tip.



See page 21 and 23 for wiring



The length will require adjustment see page 19 & 20 for angle or length adjustment.

Angle adjustment


Fully retract the boom and lower the angle to zero degrees using a angle finder to determine zero degrees. Remove the cover of the cable reel and check the +5.00vdc (Typically the voltage is about 4.94vdc) supply voltage (Brown wire) and the ground wire (white wire). The output of the angle when at zero degrees should be approximately 2.50vdc. (Green wire), (tolerance 2.49 to 2.51vdc is OK). Check the angle indication on the display (18) for accuracy at zero degrees.

If it is not correct loosen the three mounting screws with a flat tip screwdriver and adjust the pot until the angle indicates zero degrees on the display. Tighten the screws and check it at other angles for accuracy.

18



Angle sensor (ASA)




Length adjustment

Check the voltage output of the length pot is approximately .250vdc (yellow wire), (tolerance of .249 to .251)with fully retracted boom, if not adjust the length gear assembly until it is. Check the length indication on the display (19). If it is correct , extend the boom and check the fully extended length. The Brown wire (supply voltage) and White wire (Ground) used for the angle is the same supply voltage and ground for the length.



Length sensor and gear assembly



Length	Min	Max	Pull/Pin
3612	29.1'	70.0'	Full Power
3612	29.7'	71.3'	Full Power
6010	32.6'	80'	Full Power
8012	39'	90'	Full Power
9010	34'	105'	Full Power
10010MX	37.5'	111.6'	4 section
14010	37.5'	111.6'	4 section
15010	37.5'	111.6'	4 section
20010	42'	128'	
200RS	26.1'	54.1'	
26011	16.6"	27.3'	
30011	27.7'	42.7'	

A-2-B wiring

The circuit is supplied at 10-30 vdc.

A-2-B wire terminal	Connector terminal	
Yellow wire 22	N	4.7k resistor inline
White wire 21	L	

Cable reel end.


Cable reel wires	Connector wire terminals
Red wire	N
White wire	L



Pressure sensors


Troubleshooting the pressure sensors is used in the auto diagnostics in the operators manual.

Threads on pressure sensors are 1/4"BSPP



TECHNICAL SPECIFICATIONS

PIN CONNECTIONS



PIN 3 Wires

- 1 +VB
- 2 output signal 0,5 .. 5,5 V
- 3 GND

INPUT DATA

- Measuring ranges
- Overload ranges
- Max pressures
- Parts in contact with oil

350 bar
800 bar
2000 bar
Stainless steel ; Viton seal

OUTPUT DATA


- Output Signal

0,5 ... 5,5V

OTHER DATA

- Supply voltage
- Current consumption
- Life expectancy

0 - 12 ...30V
ca. 15mA
10⁶ load cycle



REVISION

GEORGIO F.	DEVIDIO F.	APR/2014
ELETTRONICA INDUSTRIALE		
S.p.A. - V.le VENTURA, 10 - 36060		
BREVETTI PIRELLI - V.le VENTURA, 10 - 36060		
V.le VENTURA, 10 - 36060		
REDA	INT.	REDA
REDA	REDA	REDA

Wiring Diagram

1. IDENTIFICATION

2. IDENTIFICATION

3. IDENTIFICATION

4. IDENTIFICATION

5. IDENTIFICATION

6. IDENTIFICATION

7. IDENTIFICATION

8. IDENTIFICATION

9. IDENTIFICATION

10. IDENTIFICATION

11. IDENTIFICATION

12. IDENTIFICATION

13. IDENTIFICATION

14. IDENTIFICATION

15. IDENTIFICATION

16. IDENTIFICATION

17. IDENTIFICATION

18. IDENTIFICATION

19. IDENTIFICATION

20. IDENTIFICATION

21. IDENTIFICATION

22. IDENTIFICATION

23. IDENTIFICATION

24. IDENTIFICATION

25. IDENTIFICATION

26. IDENTIFICATION

27. IDENTIFICATION

28. IDENTIFICATION

29. IDENTIFICATION

30. IDENTIFICATION

31. IDENTIFICATION

32. IDENTIFICATION

33. IDENTIFICATION

34. IDENTIFICATION

35. IDENTIFICATION

36. IDENTIFICATION

37. IDENTIFICATION

38. IDENTIFICATION

39. IDENTIFICATION

40. IDENTIFICATION

41. IDENTIFICATION

42. IDENTIFICATION

43. IDENTIFICATION

44. IDENTIFICATION

45. IDENTIFICATION

46. IDENTIFICATION

47. IDENTIFICATION

48. IDENTIFICATION

49. IDENTIFICATION

50. IDENTIFICATION

51. IDENTIFICATION

52. IDENTIFICATION

53. IDENTIFICATION

54. IDENTIFICATION

55. IDENTIFICATION

56. IDENTIFICATION

57. IDENTIFICATION

58. IDENTIFICATION

59. IDENTIFICATION

60. IDENTIFICATION

61. IDENTIFICATION

62. IDENTIFICATION

63. IDENTIFICATION

64. IDENTIFICATION

65. IDENTIFICATION

66. IDENTIFICATION

67. IDENTIFICATION

68. IDENTIFICATION

69. IDENTIFICATION

70. IDENTIFICATION

71. IDENTIFICATION

72. IDENTIFICATION

73. IDENTIFICATION

74. IDENTIFICATION

75. IDENTIFICATION

76. IDENTIFICATION

77. IDENTIFICATION

78. IDENTIFICATION

79. IDENTIFICATION

80. IDENTIFICATION

81. IDENTIFICATION

82. IDENTIFICATION

83. IDENTIFICATION

84. IDENTIFICATION

85. IDENTIFICATION

86. IDENTIFICATION

87. IDENTIFICATION

88. IDENTIFICATION

89. IDENTIFICATION

90. IDENTIFICATION

91. IDENTIFICATION

92. IDENTIFICATION

93. IDENTIFICATION

94. IDENTIFICATION

95. IDENTIFICATION

96. IDENTIFICATION

97. IDENTIFICATION

98. IDENTIFICATION

99. IDENTIFICATION

100. IDENTIFICATION

Engine Icons

Oil Pressure, Oil Temperature, and Water Temperature are red or RPM gauge, Water Temperature, Battery gauge, Oil pressure gauges are Inoperable.

These icons are supplied to the system via the CAN BUS/ECM on the engine directly. Check that the 6 pin connector is connected to the back of the View display. If it is connected check it for any damage to the wire to the ECM on the engine. If no damage exists, replace the View display or contact Mantis Crane Service.

Air Filter Warning, Hydraulic Oil temperature, Pilot filter Warning, or Hydraulic oil filter icon are red;

These icons are digital inputs to the View system via a 6 pin connector behind the operators seat. These inputs are switched to ground to enable the icon. The inputs can be checked by disconnecting the 6 pin connector and inserting a small wire on the system wire harness side Into the proper pin out and connect it directly to a ground. If the icon color is no longer red the issue is between the connector and the sensor.

If the icon is still red check the wiring to the head unit, and the 4 pin connector on the View Display, if no damage exists replace the Head unit. The Head unit controls these inputs.

Water in Fuel Warning ;

This icon is a digital input to the View system via a 6 pin connector behind the operators seat. This input is a 12vdc switched input to enable the icon. The input can be checked by disconnecting the 6 pin connector and inserting a small wire on the system wire harness side

Into the proper pin out and connect it directly to a 12 vdc source. If the icon color is no longer red the issue is between the connector and the sensor.

If the icon is still red check the wiring to the head unit, and the 4 pin connector on the View Display, if no damage exists replace the Head unit. The Head unit controls this input.

Fuel Gauge:

This gauge is a ohm value. When the gauge is indicating empty the value should be around 80-90 ohms on the sending tank unit and wiring harness. The ohm value is around 0 when the gauge indicates full. The unit will indicate a Low Fuel Level message at the 12% level and the audible alarm will sound. The audible alarm can be silenced momentarily by press and releasing the horn pushbutton.

<i>Rev 1</i>	<i>10-19-11</i>	<i>Revised email address on front page</i>
<i>Rev 2</i>	<i>11-28-11</i>	<i>corrected page 19 length indication</i>
<i>Rev 3</i>	<i>12-14-11</i>	<i>added new wire harness page 27 with disconnects page 29 layout, wiring additions, plus new software version 1.5A0</i>
<i>Rev 4</i>	<i>1-19-12</i>	<i>Updated for 1.5A1 software. Changed angle/length output tolerances page 5,6,7,8,22 and 23</i>
<i>Rev 5</i>	<i>2-9-12</i>	<i>Changed logo and contact information on cover page to COBO International.</i>
<i>Rev 6</i>	<i>11-6-12</i>	<i>Updated to 1.5A2 software version. No changes for troubleshooting. Cover page updated only.</i>
<i>Rev 7</i>	<i>2-21-13</i>	<i>Contact information change cover page.</i>
<i>Rev 8</i>	<i>3-28-19</i>	<i>SW version up to 1.5A4</i>
<i>Rev 9</i>	<i>6-28-19</i>	<i>Corrected alarm code 13 and 23 text page 5 & 6.</i>